INSTRUCTION MANUAL (DETAILED VERSION)

HIGH SPEED MULTI-TRANSDUCER

<u>HSQT2-500</u>



\bigcirc DAIICHI ELECTRONICS CO., LTD.

Contents

Introduction 2
Safety precaution 2
Composition of type 3
1. Features of product ······ 4
2. Dimensions and part names ····· 4
3. Bundled items ····· 4
4. Installation instructions ······ 4
5. Connection ····· 6
6. Operation · Screen · · · · · · 8
6.1 Basic operation ······ 8
6.2 Screen structure ····· 8
7. Display mode ····· 8
7.1 Measurement display ····· 8
7.2 Setting value display 10
8. Setting mode ······ 11
8.1 Setting flow ······ 11
8.2 Setting method ······ 11
8.3 Setting menu ····· 12
9. Test mode 21
9.1 Test flow
9.2 Test menu ····· 21
10. Specifications ······ 22
10.1 Rating ······ 22
10.2Measurement item, Class index2310.3Detailed specification23
10.4Measuring range2710.5Input - output characteristic example29
11. Multi-transducer setting software (QT2-CS-01)3311.1Outline33
11.2 Operating environment ······ 33
11.2 Operating environment 33 11.3 System configuration 33
12. Troubleshooting ····································

Introduction

Thank you for your purchase of DAIICHI product. Please read this instruction manual carefully before use. Keep this manual for future reference. Please contact us in case this manual is lost or damaged.

Safety Precaution

Environment conditions

- Please be sure to use this product in a place that meets the following conditions. In places that do not meet this condition, malfunctions and failures, and performance and product life may be reduced.
 ① Within the range of ambient temperature (-10 to 55 °C), humidity (5 to 90 % RH).
 - ② Place free of corrosive gas. (Corrosive gas: SO2 / H2S, etc.)
 - ③ Place free of dust, salt and oily smoke.
 - ④ Location that is not affected by vibration and shock.
 - (5) Location that is not affected by external noise.
 - 6 Altitude 2000m or less.
- If the input to this product is an inverter output such as cycle control, SCR phase angle control and PWM control, measurement error may increase.

Outdoor use conditions.

- ① This product is not dustproof, waterproof, and splash proof.
 - Please avoid the place with much dust. Please do not install in the place directly exposed to the rain and water droplets. (IP code: IP30)
- ② Please do not install in the place directly exposed to the sun even through the glass. Discoloration and degradation of a name plate, and deformation of the box by the surface temperature rise may cause.
- $\$ Product life may shorten when the daily average temperature exceeds 40 $^\circ\!\! C$.

Mounting and wiring

Please refer to this instruction manual for installation and the wiring.

Please	refer to this instruction manual for installation and the wiring.				
	 Please refer to connection diagram for the wiring. 				
	An improper connection may cause generation of high voltage on the CT secondary side, and				
	which may lead to device malfunction, burning or fire.				
• Hot line work is prohibited. There is a risk of explosion by electric shock, devi					
	malfunction, burning, fire, or gas.				
	 Please use an electrical wire size suitable with the rated current. 				
CAUTION Use unsuitable size electric wire, which may lead to a fire.					
• Please check the tightening of the screw. If the screws are loose, it may cause a f					
malfunction.					
	• The terminal cover is installed for preventing an electric shock accident.				
	Please close terminal cover after wiring work.				

Preparation

This product must be set before use. Please read this manual and make the setting correctly.

If you make a mistake on the setting it does not operate correctly.

Maintenance and inspection

- ① Inspection during energization is dangerous and prohibited.
- ② No replacement in periodic inspection.
- ③ Check for loose wiring and mounting screws.
- ④ Please wipe off lightly with the dry soft cloth for cleaning.

Please do not use organic solvents such as alcohol, chemicals, or cleaners.

 Storage When storing this product for a long period, please keep it in a place that satisfies the following environmental conditions. Within the range of ambient temperature (-20 to 70 °C) and humidity (5 to 90 %RH). Place where average daily temperature does not exceed 40 °C. Locations with little dust, corrosive gases, salt and oil smoke. A place not subject to vibration or shock.
■ Countermeasures against troubles We will take back the actual product for repair in principle if it breaks down.
■ Disposal Please dispose of this product as industrial waste (noncombustible). Mercury parts and a nickel-cadmium battery are not used for this product.
Warranty period The warranty period of the product is one year after the date of delivery.
 Warranty scope In the state of the normal use of product-specification within the range according to this instruction manual, this product in trouble within the warranty period will be performed exchange or repair gratuitously. However, it is not warranted in the following cases. ① If it breaks down when converted or repaired without us. ② If it breaks down by use out of specification range. ③ If the cause of trouble is based on cause other than this product. ④ Damage and trouble by transportation, movement, and falling. ⑤ In other cases where the supplier is not responsible due to disasters, etc. This warranty is a warranty only for the delivered product. Cannot warrant the damage induced by trouble of this product.
■ Replacement cycle of the product We recommend updating the product for 10 years as a rough standard.
■ Change of instruction manual written contents.

This instruction manual changes written contents without a notice by product improvement etc.

Composition of type

Туре

Specification code

HSQT2-500-

	(1	D Auxiliary supply			
	1	80 to 264 V AC 80 to 264 V DC		1	0 to 5 V DC (6
		For AC and DC use		2	0 to 10 V DC (
	2	20 to 57 V DC		3	1 to 5 V DC (6
				4	-5 to 5 V DC (

supply		② Analog output					
AC DC	1	0 to 5V DC (600 Ω to $\infty)$	А	0 to 1 mA DC (0 to 10 k $\Omega)$			
DC use	2	0 to 10 V DC (2 k Ω to $\infty)$	В	4 to 20 mA DC (0 to 550 $\Omega)$			
)C	3	1 to 5 V DC (600 Ω to $\infty)$	С	-1 to 1 mA DC (O to 10 k $\!\Omega)$			
	4	-5 to 5V DC (600 Ω to $\infty)$	Ζ	Other (special specification)			
	5	-10 to 10 V DC (2 k Ω to $\infty)$					

3

1. Features of product

- Compliant with IEC60688 : 2012 (Transducer), IEC62053 : 2003 (Static meters for active energy, Static meters for reactive energy).
- CE marking product
- Possible to change by setting. (Wiring type, rated voltage, rated current)
- High-speed response [Input, 1 cycle + 10ms or less/99%, Frequency: Input, 2 cycles + 15ms or less/99%]
- Standard equipment; 10-analog output, 2-pulse output, RS-485 Communication output (MODBUS).
- Connected to a PC with USB, you can write and read settings in dedicated software. About the setting software, it is downloadable from our web site. URL; https://www.daiichi-ele.co.jp/
- Using an organic electro-luminescence display of high contrast. Configuration changes, measurement items can be displayed.
- Wiring after installation can be confirmed in the test output by the front operation. To display the phase angle between the voltage and current, and supports the determination of the wiring mistake points.



3. Bundled items

- ② Attachment tool ······ 4
- ③ Termination resister for communication (100 Ω) $\cdots \cdots 1$

4. Installation instructions

Please select indoors without low mechanical vibration, dust, and corrosive gas.

There is no limit of a mounting position.

A mounting means can be selected from IEC 35 mm rail (DIN rail) mounting and screw mounting.

Please separate the mounting side-by-side interval by 10 mm or more as a measure against heat.

Please consider heat and separate more than 10 mm of the interval of mounting side by side.

Please consider heat and wiring space and separate more than 90 mm of the space above and below. Please secure the space distance of a terminal and a metal panel 10 mm or more.

<u><CAUTION> Please do installation of a product and removal after a power supply and an input signal are</u> <u>stopped.</u> ■ Mounting the IEC 35 mm rail (DIN rail) The product slider is at the bottom. Position the upper hook at the rear side of product on the DIN rail and push in the lower.



IEC, DIN rail (35mm width)

■ Removal from IEC 35 mm rail (DIN rail)

Insert a flat-blade screwdriver into the square holes of the sliders (2 places). While pulling out the two sliders in the direction of ${f O}$ at the same time, pull up the product in the direction of ${f O}$. The product can be removed from the rail by simply pulling out the slider 1.5 mm.



Flat-blade screwdriver

<CAUTION>

If you pull out the slider by moving the screwdriver like a lever, or pull up the product without pulling out the slider, the product may be damaged.





Screw mounting Attach the included mounting leg $(\times 4)$. Please install with M4 screw or M5 screw. Tightening torque, M4 : 1.00 to 1.30 N⋅m Tightening torque, M5∶2.00 to 2.50 N·m



54 65 /ᡛᡃᡗ\ ሞካ Φ Φ 110 HSQT2-500 HSQT2-500 ШIJ WW ð ð Ð ГÐ 10 10 10 6 65 54 65 /ፑΨ∖ ത æ Þ ቀ ጦካ 110 HSQT2-500 HSQT2-500 WW WW J J J เฮิ 10 10 10

<CAUTION> Please mount a product from the bottom to prevent a fall.

5. Connection

Open the terminal cover, please connections according to the wiring diagram below. Terminal numbers and names are listed on the back of the terminal cover.





Maximum rated voltage

	3P4W	3P3W (Ground)	3P3W (Ungrounded)	1P2W (Ground)	1P2W (Ungrounded)	1P3W
Wiring type						
Maximum rated voltage	277 V (L-N) 480 V (L-L)	220 V (L-L)	480 V (L-L)	220 V (L-L)	480 V (L-L)	220 V (L-N) 440 V (L-L)

• In the case of the low-pressure circuit (600 V or less), the secondary grounding of VT / CT is not required.

 \cdot Ground terminal (No.15), please be sure to ground. Ground is a class D grounding (grounding resistance less than 100 $\Omega).$

• When using with three-phase four-wire (2VT3CT), voltage balance is a condition.

• Output wiring and the noise source (power line, steep voltage, the wire there is a current fluctuation), please release as much as possible. Please use a twisted cable or twisted cable shielded.

Minus (-) terminals are connected internally of analog output CH1 to 5. (Common, Non-isolated)
 Minus (-) terminals are connected internally of analog output CH6 to 10. (Common, Non-isolated)

• Be used open the analog output terminal (current output), there is no damage to this product.

- Termination resistor for the communication output, please use at the end of equipment.
- Please connect the termination resistor between the RS-485 of (+)(-) terminals.

• After the wiring work, please close the terminal cover.

6. Operation and Screen 6.1 Basic operation POWER ON MENU DISPLAY Selection screen 183 DI SPLAY ute MENU ዏ SET 1.MEASUREMENT Display DISPLAY 2.SET VALUE mode †∔ TEST MODE ISQT2-500 (P8-) SETTINGS MODE BACK SET ENTER MODE DSP OFF SET ENTER MODE A TEST Confirmation screen Selection screen Display OFF Switch t‡ TEST TEST operation YES Test DISPLAY 1.AO OK? SET 2.90 †↓ TEST mode YES NO 3.COMM 🔒 🗱 SETTINGS (P21-) **4.WIRING CK** MODE MODE DSP OFF (SET)ENTER SETIENTER MODEIBACK MODEBACK (SET)ENTER MODE TEST/SETTING Locked. SETTINGS 1 sec. (1) During the lock cannot Selection screen Confirmation screen be migrated to the test + ISETTINGS SETTINGS mode and setting mode. YES Setting @ IN ЛPO UK3 SET SET mode ∿MEAS 🖓 COMM YES NO No operation (1 to 30 min. : Setting) **₽** CFG 🛛 A0 (P11-) MODE BACK MODEIBACK SET ENTER **SETIENTER** MODE is pressed with each screen, return to the previous screen. (Confirmation screen skips.)

Note (¹) By pressing and holding the switch for more than one second, it returns from each of the screen to the MENU screen.



 I
 0 to 5 A
 0 to 100.0 %

 U, FU
 0 to 150 V
 0 to 100.0 %

 P/Q/S
 -1 kW/kvar/kVA to 1 kW/kvar/kVA
 -100.0 to 100.0 %

Displays the actual measured values of power factor, frequency, and active and reactive energy. Refer to section 10.4 for details.

- (2) Operation

 - (3) Measurement item

Page	Measurement	Screen	Wiring type				
Paye	disp		3P3W	3P4W	1P2W	1P3W	
1	Current, Current (power flow)	Ι	1, 2, 3, avg (²)	1, 2, 3, N, avg (²)	Ι	1, 3, N	
2	Line voltage, Phase voltage	U	12, 23, 31, avg (²)	12, 23, 31, LLavg 1N, 2N, 3N, LNavg (³)	U	13, 1N, 3N	
3	Active power	Р	Σ (2)	1, 2, 3, Σ (²)	Р	Σ (2)	
4	Reactive power	Q	Σ (2)	1, 2, 3, Σ (²)	Q	Σ (2)	
5	Apparent power	S	Σ (2)	1, 2, 3, Σ (²)	S	Σ (2)	
6	Power factor	PF	Σ (2)	1, 2, 3, Σ (²)	PF	Σ (2)	
7	Frequency	f	f	f	f	f	
8	Active energy	Wh	Incoming (+) / Outgoing (-)				
9	Reactive energy (Incoming)	+varh	LAG / LEAD				
10	Reactive energy (Outgoing)	-varh	LAG / LEAD				
11	Fundamental voltage	FU	12, 23, 31, avg (²)	1N, 2N, 3N, avg (²)	FU	1N, 3N	

Note (²) avg : Average, Σ : Total.

Note (³) Since the line voltage and phase voltage that are displayed on two pages, the following page numbers are +1. (3P4W)

7.2 Setting value display

(1) Display

Example: Analog output settings



Page	Setting item	Display	Setting contents
	-	Тор	Wiring type
1	Input	Center	VT ratio
		Bottom	CT ratio
		Top	CH No.
2 to 11	Analog output	TOP	Output factor
2 10 11	Analog output	Bottom	Input range for output
			value
12		Top	CH No.
12	Pulse output	TOP	Output factor
15		Bottom	Output pulse rate
		Тор	CH No.
14	Communication	TOP	Protocol
14	output	Center	Address
		Bottom	Bit rate

(2) Operation

-	SET → Γ SET VALUE」 SET → ue to be displayed. (\blacktriangle		е.
No.1 Input settings	No.2 to 11 Analog output settings	No.12,13 Pulse output settings	No.14 Communication output settings
	← CH1 : P1 ← CH1		Image: Big Disp>set VALUE CH13: MODBUS RTU MODRESS 1 9600 bps MODEBACK⊡PREU⊡NEXT

8. Setting modes



- \oslash When the setting is confirmed, to display the " \checkmark " indicating the current setting in place of the changed setting value.
- 3 When \blacktriangle \blacksquare is pushed lengthily, the set value changes at high speed.

8.3 Setting menu

(1) Input setting IN							
Setting item	Description	Content					
	Set wiring type of	[Wiring type] [Number of CT] Thick-frame:Default setting					
	input circuit.	SETIN>WIRING TYPE					
	3P3W sets up the number of CT.	3PHW 2VT2CT 2 phace 2 wire 2D2W 2V1,2C1					
	3P4W sets up the	1P2W 2VT3CT 3=phase 3=wire 3P3W 2VT, 3CT					
Wiring type	number of VT.	MODE BACK SET ENTER MODE BACK SET + SET 3-phase /-wire 3P/W 2VT, 3CT					
[WIRING TYPE]		3VI, 3CI					
		1-phase 2-Wire 1P2W					
		<u>CAUTION> If this setup is performed,</u> <u>1-phase 3-wire</u> <u>1P3W</u>					
		<u>all set points will be initialized.</u>					
		<u>Please set up first.</u>					
	Set in accordance	[VT select] [Primary voltage] Setting range					
	with the use VT. Primary voltage						
	- PRIMARY,	PRIMARY 11kV voltage					
	Secondary voltage	13.2kV 110 V 6600 V 66 kV 110 V 13.8kV 110 V 220 V 11 kV 77 kV 220 V					
	- SECONDARY	Inddel back Set Jenter Inddel back Set Jenter 440 V 13.2 kV 110 kV 440 V					
VT		Default setting 880 V 13.8 kV 132 kV -					
[VT]		3P3W: 6600 V/110 V 1100 V 16.5 kV 154 kV -					
		3P4W: 440 V/440 V (Direct) 1650 V 18.4 kV 187 kV -					
		1P2W : 3300 V/110 V 2200 V 22 kV 220 kV -					
		1P3W: 110 V/110 V (Direct) <u>3300 V 33 kV</u>					
	<u><caution> In direct connection, please set a primary voltage and a second</caution></u>						
		voltage as the same value.					
	Set in accordance	(Primary/Secondary) (Primary current) Setting range Setting range Setting range					
	with the use CT. Primary current	SECONDARY					
	- PRIMARY,	PRIMARY TSA SOR 5 A 60 A 750 A 5000 A 5 A					
	Secondary current						
	 SECONDARY 	TODEBACK SETENTER TODEBACK SETISET 7.5 A 80 A 900 A 7500 A -					
СТ		Default setting 8 A 100 A 1000 A 8000 A 10 A 120 A 1200 A 1000 A					
[CT]		3P3W : 100 A/5 A 10 A 120 A 9000 A - 3P4W : 1500 A/5 A 12 A 1500 A 10 kA - <					
		3P4W : 1500 A/5 A 12 A 1500 A 1500 A 100 KA - 1P2W : 50 A/5 A 15 A 200 A 1600 A 12 KA -					
		1 P3W · 500 A/5 A 20 A 250 A 1800 A 15 kA -					
		25 A 300 A 2000 A 20 KA -					
		<u>30 A 400 A 2500 A 30 kA</u> 40 A 500 A 3000 A					
		50 A 600 A 4000 A -					
	Set phase voltage	[3P4W] [1P3W] 110 V rating					
	values for the upper	set INAULN SCALE Setting range					
	limit of the analog	✓ 150/√3V					
Phase voltage	output rating. (3P4W	150 / √3 V 150 V					
full-scale	and 1P3W)						
[ULN SCALE]	In case of 3P3W and 1P2W, there is no	Example of setting					
	setting item.	Wiring type Setting value Input / Output					
		3P4W 150/√3 V U1N, U2N, U3N 0 to 86.6 V / 4 to 20 mA					
		1P3W 150 V U1N, U3N 0 to 150 V / 4 to 20 mA					

(2) Measurement setting MEAS

Setting item	Description		Content		
Current range 【I RANGE】	Set current measurement values for the upper limit of the analog output rating range.		Setting r 100.00 to 120 f setting (CT ra alue I	rame : Default setting ange 0.00 % 0.01 % step tio : 100 A / 5 A) nput / Output a (/4 A) / 4 to 20 mA	Rated current =100.00 %
Voltage range 【U RANGE】	Set voltage measurement values for the upper limit of the analog output rating range.		Setting r 150.00 to 18 f setting (VT ra alue I	rame: Default setting range 0.00 % 0.01 % step atio:6600 V / 110 V) nput / Output V (/150 V) / 4 to 20 m	Rated voltage =110.00 %
Active power range [P RANGE]	Set active power measurement values for the upper limit / lower limit of the analog output rating range.	Upper0.00 to100.00Lower-120.00to• The output element when the is the upper setting from the upper setting is leaded output range (in constructed output ranges from the select the next output endition, in the case range of lower setting from the case range of lower setting from the setting from the case range of lower setting fr	ing range to 120.00 % 0.00 % ne "+ Σ P, + P1, m zero. (Lower ess than 20 %, ase of 4 to 20 e lower setting lement. " $\pm \Sigma$ P, where the upper rom zero. 1000 W (110 V, Upper s settings % 83.33 % % 66.67 % % 0.00 % % 0.00 % % 0.00 % % 0.00 %	Default setting 0.01 % step 0.01 % step 1.1 % 0.00% 5 A)] 1.1 % 0.00% 5 A)] 1.1 % 0.00% 5 A)] 1.1 % 0.00% 1.1 % 0.00% 1.1 % 0.00% 1.1 % 0.00% 1.1 %) wer limit of the setting, please will be in the o 20 mA o 5 V / -5 to 0 to 5 V to 20 mA 20 mA r limit of +ΣP) e difference of

Catting item	Decerintian	Contont
Setting item	Description Set operation method	Content
	Set operation method of reactive power. And, set reactive power measurement values for the upper limit / lower limit	COperation method / Range) CArithmetic) ENTHED ENTHOD METHOD Carithmetic) RANGE Carithmetic) ImodelBack Setting range
	of the analog output rating range.	Thick-frame : Default settingSetting range (Positive : LAG, Negative : LEAD)Upper0.00 to100.00to120.00 %0.01 % stepLower-120.00 to-100.00to0.00 %0.01 % step
		 In the case where the upper setting to 0.00 %, will be in the range of lower setting (LEAD) from zero. If the analog output element is a reactive power (power flow), it will be the lower setting = negative upper setting. (Lower setting is invalid) If the upper setting is less than 20 %, the output is the lower limit of the rated output range (in case of 4 to 20 mA, 4 mA). In this case, the upper limit set value is set to 20 % or more. Example of setting [Rating 1000 var (110 V, 5 A)])
		No. Lower Upper Input / Output
Reactive power		1 -75.00 % 75.00 % LEAD 750 to 0 to LAG 750 var / -5 to 0 to 5 V
		2 -25.00 % 100.00 % LEAD 250 to LAG 1000 var / 4 to 20 mA 3 0.00 % 83.33 % 0 to LAG 833.3 var / 4 to 20 mA
		3 0.00 % 83.33 % 0 to LAG 833.3 var / 4 to 20 mA 4 -83.33 % 0.00 % 0 to LEAD 833.3 var / 4 to 20 mA
		<caution> It cannot change into the set point from which the difference of upper set point and lower set point becomes less than 20 %.</caution>
		[LAG/LEAD polarity]
		Incoming (Power purchase)
		Current of leading phase Reference V
		$270^{\circ} \left(\begin{array}{c} LEAD \\ LAG \\ LEAD \\ LEAD \\ LAG \end{array} \right) 90^{\circ}$
		180°
		Outgoing (Power selling) During outgoing (P<0), polarity as viewed from the incoming side (Reference V fixed)

		• · · · · · · · · · · · · · · · · · · ·
Setting item	Description	Content
	Set output method of reactive power (power flow).	Operates with the upper limit setting of reactive power. (Lower limit value = negative upper setting) Set the upper limit value to 20% or more. If set to less than 20%, the output will be the lower limit of the rated output range.
	SET MEAS>QP f	Thick-frame: Default setting
		Setting range
		4 quadrant 4QUADRANT 2 quadrant 2QUADRANT(+)
	<u>ftode</u> back <u>(set</u> iset	20mA 20mA 12mA 12mA 4mA Outgoing 1 LEAD 0 LAG 1 LEAD 0 LAG 1 LEAD 0 LAG 1 LEAD 0 LAG 1 LEAD 0 LAG 1 LEAD 0 LAG 1
		2 quadrant 2QUADRANT 2 quadrant 2QUADRANT(-)
Reactive power (power flow)		20mA 20mA 12mA 20mA 4mA Outgoing Incoming 4mA 0utgoing Incoming
[Qpf]		 In the pattern of the two-quadrant (incoming only), is the output of the equivalent Ovar at the time of outgoing. In the pattern of the two-quadrant (outgoing only), is the output of the equivalent Ovar at the time of incoming.
		[LAG/LEAD polarity]
		Incoming (Power purchase)
		Current of leading phase LEAD LAG (Incoming)
		270° LAG Current of
		lagging phase 180° leading phase Outgoing (Power selling)
		During outgoing (P<0), polarity as viewed from the outgoing side (Reference V, 180° inversion)
Apparent power range [S RANGE]	Set apparent power measurement values for the upper limit / lower limit of the analog output rating range.	Please set up similarly with reference to a setup (P13) of current range.Thick-frame : Default settingSetting range30.00 to100.00to 120.00 %0.01 % step= 100.00 %

Setting item	Description	Contant
Setting item Power factor range 【PF RANGE】	Description Set power factor measurement value to the rated output range of the analog output.	Content Thick-frame : Default setting Setting range Output (Example) LEAD 0.5 to 1 to LAG 0.5 4 to 12 to 20 mA LEAD 0.5 to 1 to LAG 0.5 4 to 12 to 20 mA LEAD 0.5 to 1 to LAG 0.5 4 to 12 to 20 mA LEAD 0.5 to 1 to LAG 0.5 1 to 3 to 5 V LAG 0.5 to 1 to LEAD 0.5 -1 to 0 to 1 mA LAG 0 to 1 to LEAD 0 -5 to 0 to 5 V Incoming (Power purchase) Current of LEAD LeAD LeAD -5 to 0 to 5 V Incoming (Power purchase) Current of LeAD LAG 90° LEAD LAG 90° 180°
		Outgoing (Power selling) During outgoing (P<0), polarity as viewed from the incoming side (Reference V fixed)
Power factor (power flow) 【PFpf】	Set output method of power factor (power flow). Please set up similarly with reference to a setup (P15) of reactive power (power flow).	Thick-frame : Default setting Setting range A quadrant 4 quadrant 4 quadrant 2 quadrant 2 QUADRANT 2 quadrant (Incoming) 2 QUADRANT 2 quadrant (Outgoing) 2 QUADRANT(+) 2 quadrant (Outgoing) 2 QUADRANT(-) Incoming (Power purchase) Current of Current of Incoming (Power purchase) Current of LEAD LAG LEAD Image Current of Incoming Q0° Current of LEAD LAG LEAD LAG Current of leading phase Outgoing (Power selling) During outgoing (P<0), polarity as viewed from the power outgoing side
Frequency range [f RANGE]	Set frequency measurement value to the rated output range of the analog output.	SetTing rangeThick-frame : Default settingVH5-55HzVS5-65HzSetting rangeOutput (Example)45 to 55 Hz4 to 20 mAV5-65Hz55 to 65 HzTIDDEBACKSETISET

Setting item	Description			Content			
Wh/varh unit per count [Wh/varh]	Set unit per count of Wh/varh (display and communication data).	Over 1 Over 10 Over 100 Over 1,000 Over 10,000 Over 100,000 Over 1,000,000	 Integrating th digit, up to a Integrate agai Full load powe = K×VT prima K : 3P3W, 3P4W= wer kW/kvar Below 1 Below 10 Below 100 Below 10,000 Below 10,000 Below 10,000 Below 10,000,000 Below 100,000 	e set value maximum o n from "0" r (kW/kvar ry voltage √3, 1P2W= 0utput 0.01 0.1 (4) 10 (4) 100 (4) 1,000 - - -	f 9 digits if it exce (V)×CT pri 1, 1P3W=2 Thick-fr pulse rate, 0.001 0.01 0.01 (4) 10 (4) 100 (4) 1,000 - -	(9999999999 eeds 9 digi imary curre rame : Defaul . kWh(kvarh). 0.0001 0.001 0.001 0.01 0.01 0.1 (4) 10 (4) 100 (4) 1,000 -). ts. nt (A)×10 ⁻³ t setting /pulse 0.0001 0.001 0.001 0.01 (⁴) 10 (⁴) 1,000
Moving average number of times 【CNT AVG】	Set the moving average number of times for every measurement value.	SETMEAS>CHT AVG ✓1TIME 2TIMES 3TIMES © 1000BBACK SETSET	Sett	e:Default ing range ng average,			

(3) Analog output setting AO

Setting item	Description	Content							
	The measurement element outputted to CH1 to 10 is set up from the pattern prepared	SERIAD>PATTERN MANUAL NORMAL ✓ISOLATION		e of elem	ents set			it will e:Defaul [:]	be MANUAL.
	beforehand.	Setting	range	Phase	CH1	CH2	CH3	CH4	CH5
		Individual	MANUAL	All		For eac	h element	setting	
				3P3W	I1	I2	I3	U12	U23
		Standard	NORMAL	3P4W	I1	I2	I3	U1N	U2N
		Stanuaru	NORMAL	1P2W	Ι	U	+ P	Q	PF
				1P3W	I1	I3	IN	U1N	U3N
Output				3P3W	lavg	FULLavg	+∑P	ΣQ	f
pattern		Isolated 2 ISOLATI	ISOLATION	3P4W	lavg	FULNavg	+ΣP	ΣQ	f
(PATTERN)		outputs	IJULATION	1P2W	Ι	FU	+P	Q	f
				1P3W	I1	FU1N	+∑P	ΣQ	f
		Setting	range	Phase	CH6	CH7	CH8	CH9	CH10
		Individual	MANUAL	All	CHU		h element		CITU
		Individual	MANOAL	3P3W	U31	$+\Sigma P$	ΣQ	ΣPF	f
				3P4W	U3N	$+\Sigma P$	ΣQ	ΣPF	f
		Standard	NORMAL	1P2W	f	OFF	0FF	0FF	0FF
				1P3W	U13	+ΣP	ΣQ	ΣPF	f
				3P3W	lavg	FULLavg	+ΣP	ΣQ	f
		Isolated 2		3P4W	lavg	FULNavg	+ΣP	ΣQ	f
		outputs	ISOLATION	1P2W	Ι	FU	+P	Q	f
				1P3W	I1	FU1N	+∑P	ΣQ	f

Setting item	Description			Content			
	Set measurement	[CH set]		[Element]			
	element outputted	SET AO>ELEMENT		Delemoch1	5		
	to CH1 to CH10.	CH1) []			5		
	(CH individual)	СНЗ	IF	of			
				BACK (SET)SET			
			<u>[11515</u>		_		
		Measurement	Measurands	0.0014	Wiring type	4 5 0 14	4 5014
		Current	T	3P3W 1, 2, 3, avg	3P4W 1, 2, 3, N, avg	1P2W	1P3W 1, 3, N
		Current (power flow)	I Ipf	1, 2, 3, avg	1, 2, 3, N, avg	Ipf	1, 3, N
		Line voltage,		12, 23, 31,	12, 23, 31, LLavg,		
		Phase voltage	U	LLavg	1N, 2N, 3N, LNavg	U	13, 1N, 3N
		Active power	Р	$+\Sigma$	$+1, +2, +3, +\Sigma$	+ P	$+\Sigma$
				±Σ	$\pm 1, \pm 2, \pm 3, \pm \Sigma$	±Ρ	±Σ
Output element		Reactive power Reactive power	Q	Σ	1, 2, 3, Σ	Q	Σ
(ELEMENT)		(power flow)	Qpf	Σ	1, 2, 3, Σ	Qpf	Σ
		Apparent power	S	Σ	1, 2, 3, Σ	S	Σ
		Power factor	PF	Σ	1, 2, 3, Σ	PF	Σ
		Power factor	PFpf	Σ	1, 2, 3, Σ	PFpf	Σ
		(power flow)	f	f	f	f	f
		Frequency		12, 23, 31,			
		Fundamental voltage	FU	LLavg	1N, 2N, 3N, LNavg	FU	1N, 3N
		1.2.2 N : a mbasa		warrana of oo	ah mhaaa 🛛 🗸 wan i		+ + + + + + + + +
		 1,2,3, N is phase. If it is set as OF 					
		rated-output range				IL Val	
		• In the case of one				(]) nl	ease select
		the +P. In the case					
		select the $\pm P$.				(-) L	11), prodoc
		See the power rang	e setting	for more in	formation. (P13)		
	Set rated-output	【CH set】	【0 to 5	5 V/1 to 5 V]	Thick-frame:I	Default	setting
	range at the time of	SET AO>SPEC	SSI AO>SF		Setting	ı range	
Output	output	CH1			0 to 5 V 1 to	5V () to 10 V
specification	specification (0 to	СНЗ		•	spec. spe		spec.
[SPEC]	5 V, 1 to 5 V, 0 to 10				0 to 5 V 0 to) to 10 V
	V).	Inobejowek jernek	<u>[[[]]][]</u>][]]	ICK (<u>BEI</u> (SET	1 to 5 V 1 to	5 V 2	2 to 10 V
	(CH individual)	In the case of other					
	Set ON/OFF of	If a setup is ON, ar					g value.
	output limiter.	Upper limit:+1 % ar			or the output spa	n.	
	(CH individual)	【CH set】 ≊TAO>LIMIT		[ON/OFF]	This is a second	failt	
		SET AU>LINII					settina
0 1 1 1 1 1		СН1 🕅		LIMIT>CH1	Thick-frame : De		Secting
Output limiter		CH1 送 一		F	Setting	range	Setting
Output limiter 【LIMIT】				F	Setting OF	range F	
		CH2 CH3		F	Setting	range F	
		СН2 СН3 СНЧ 🖂 🗲		F 121 A SACK (SET) SET	Setting OF ON	range F	
		CH2 CH3 CH4 TOODEBACK SETENTER If the output specif Limiter OFF : Range c	ication is	F 27 BACK SETSET 4 to 20 mA 23.20 mA	Setting OF ON	range F	
		CH2 CH3 CH4 TODEBACK SETENTER If the output specif	ication is	F 27 BACK SETSET 4 to 20 mA 23.20 mA	Setting OF ON	range F	
	BIAS adjustment and	CH2 CH3 CH4 TODEBACK GETENTER If the output specif Limiter OFF : Range of Limiter ON : Range of An output is fluctua	ication is f 0.80 to f 3.84 to	F (2) BACK (SET)SET 4 to 20 mA 23.20 mA 20.16 mA	Setting OF ON	range F	
	SPAN adjustment of	CH2 CH3 CH4 TODEBACK SETENTER If the output specif Limiter OFF : Range of Limiter ON : Range of An output is fluctua [CH set]	ication is f 0.80 to f 3.84 to ted by	F (2) BACK (SET)SET 4 to 20 mA 23.20 mA 20.16 mA	Setting OF ON Jjustment value is (SPAN	range F s decic adjusti	led by <u>SET</u> . ment]
	SPAN adjustment of analog output are	CH2 CH3 CH4 TODEBBACK SETENTER If the output specif Limiter OFF : Range of Limiter ON : Range of An output is fluctua [CH set] ETADYADJUIST	ication is f 0.80 to f 3.84 to ted by A	F (2) SACK SETISET 4 to 20 mA 23. 20 mA 20. 16 mA ▼ and an ac S/SPAN set] →ADJUST⊅CH1	Setting OF ON Jjustment value is (SPAN	range F I s decic adjustr	led by <u>SET</u> . ment]
	SPAN adjustment of analog output are performed according	CH2 CH3 CH4 Income BACK BETENTER If the output specif Limiter OFF: Range of Limiter ON : Range of An output is fluctua [CH set]	Tication is of 0.80 to of 3.84 to ted by (BIA (BIA	F (⊂ SACK (SET)SET 4 to 20 mA, 23. 20 mA 20. 16 mA ▼ and an ac S/SPAN set] ×ADUUSTSCH1 RS \	Setting OF ON Jjustment value is (SPAN	range F I s decic adjustr N	led by <u>SET</u> . ment]
(LIMIT)	SPAN adjustment of analog output are	CH2 CH3 CH4 TOODEBACK SETENTER If the output specif Limiter OFF: Range of Limiter ON : Range of An output is fluctua [CH set] SETAOPADJUST CH1 CH2 CH2 CH3	Tication is of 0.80 to of 3.84 to ted by (BIA (BIA	F (2) SACK SETISET 4 to 20 mA 23. 20 mA 20. 16 mA ▼ and an ac S/SPAN set] →ADJUST⊅CH1	Setting OF ON Jjustment value is (SPAN	range F I s decic adjustr	led by <u>SET</u> . ment]
(LIMIT) Output	SPAN adjustment of analog output are performed according	CH2 CH3 CH4 TODEBACK SETENTER If the output specif Limiter OFF: Range of Limiter ON : Range of An output is fluctua (CH set) SETADPADJUST CH1 CH2 CH3 CH4 CH4 CH4	Content of the second	F Construction F Construction	Setting OF ON djustment value is (SPAN SPA SPA SPA SPA SPA SPA SPA SPA	range F I s decic adjustr N	led by SET. ment]
(LIMIT)	SPAN adjustment of analog output are performed according	CH2 CH3 CH4 TOODEBACK SETENTER If the output specif Limiter OFF: Range of Limiter ON : Range of An output is fluctua [CH set] SETAOPADJUST CH1 CH2 CH2 CH3	Tication is of 0.80 to of 3.84 to ted by (BIA (BIA	F Construction F Construction	Setting OF ON djustment value is (SPAN SPA SPA SPA SPA SPA SPA SPA SPA SPA SPA	range F I s decic adjusti DJUSTRHI N 0.00 %	led by <u>SET</u> . ment】 ⊖
(LIMIT) Output adjustment	SPAN adjustment of analog output are performed according	CH2 CH3 CH4 TODEBACK SETENTER If the output specif Limiter OFF: Range of Limiter ON : Range of An output is fluctua (CH set) SETADPADJUST CH1 CH2 CH3 CH4 CH4 CH4	Cication is of 0.80 to f 3.84 to ted by A BIA SET P NODE NODE	F Construction F Construction	Setting OF ON djustment value is (SPAN SPAN SPAN SPAN SPAN SPAN SPAN SPAN	range F I s decic adjusti DJUSTRHI N 0.00 %	led by <u>SET</u> . ment】 ⊖
(LIMIT) Output adjustment	SPAN adjustment of analog output are performed according	CH2 CH3 CH4 TODEBACK SETENTER If the output specif Limiter OFF: Range of Limiter ON : Range of An output is fluctua (CH set) SETADPADJUST CH1 CH2 CH3 CH4 CH4 CH4	Contraction is of 0.80 to of 3.84 to ted by A BIA	F Construction F Construction	Setting OF ON djustment value is (SPAN SPAN SPAN SPAN SPAN SPAN SPAN SPAN	range F I s decic adjusti DJUSTRHI N 0.00 %	led by <u>SET</u> . ment】 ⊖
(LIMIT) Output adjustment	SPAN adjustment of analog output are performed according	CH2 CH3 CH4 TTOOE BACK BETENTER If the output specif Limiter OFF : Range of Limiter ON : Range of An output is fluctua [CH set] CH4 CH2 CH3 CH4 CH4 CH4 CH4 CH4 CH4 CH4 CH4	Contraction is f 0.80 to f 3.84 to ted by A (BIA ST (DE) (DE) (DE) (DE) (DE) (DE) (DE) (DE)	F C PACK SETSET 4 to 20 mA 23. 20 mA 20. 16 mA C and an ac S/SPAN set] ADJUSTEDHI PACK SETENTER Adjustment r	Setting OF ON Jjustment value is (SPAN SPA SPA SPA SPA SPA SPA SPA SPA SPA SPA	range F I s decic adjust adjust N 0.001× N 0.001× E E E E E E E E	led by <u>SET</u> . ment】 ⊖
(LIMIT) Output adjustment	SPAN adjustment of analog output are performed according	CH2 CH3 CH4 TTOOE BACK BETENTER If the output specif Limiter OFF : Range of Limiter ON : Range of An output is fluctua [CH set] CH4 CH2 CH3 CH4 CH4 CH4 CH4 CH4 CH4 CH4 CH4	Contraction is ication is if 0.80 to if 3.84 to ted by A BIA BIA SET NOTE TOTE	F (SACK (SETISET 4 to 20 mA, 23. 20 mA 20. 16 mA ▼ and an ac S/SPAN set] ADJUSTPCH1 RS) RS) RADJUSTPCH1 RS) ADJUSTPCH1 RS) RADJUSTPCH1 RS) ADJUSTPCH1 RS) C RN (SETIENTER Adjustment r	Setting OF OF ON SIJUSTMENT VALUE IS SPAN SIJUST SI	range F I s decic adjusti DUUSTRHI N 0.00 z i Defat i Defat	led by SET. ment] DET JIT setting

(4) Pulse output setting PO

Setting item	Description		Content		
	Set measuring element to pulse output to CH11 and CH12. (CH Individual)			k-frame:Defau	<u>lt settin</u> g
		Set	ting range		
Output element			CH		-112
[ELEMENT]		Pulse OFF	OFF	OFF	
		Active energy (Incoming)	+Wh	+Wh	
		Active energy (Outgoing)		-Wh	
		Reactive energy (Incoming, LAG	,		
		Reactive energy (Incoming, LEA			
		Reactive energy (Outgoing, LAG			
		Reactive energy (Outgoing, LEA	D) -varh L	EAD -varh	LEAD
	Set output pulse rate of CH11 and CH12. (CH Individual)		кwh./р Г Э ск (SET) SET Thi	ck-frame:Defau	
		Full load power (kW, kvar)	Output pulse	rate, kWh(kvarh)	/pulse
Output pulse		Below 1		0.01 0.001	0.0001
rate		Over 1 Below 10	1	0.1 0.01	0.001
[RATE]		Over 10 Below 100	10	1 0.1	0.01
		Over 100 Below 1,000 Over 1 000 Delay 10,000	100	10 1	0.1
		Over 1,000 Below 10,000 Over 10,000 Below 100,000	1,000	100 10	10
		Over 10,000 Below 100,000 Over 100,000 Below 1,000,000	,	,000 100 0,000 1,000	10 100
		Over 1,000,000 Below 1,000,000), 000 10, 000	1,000
		Over 10,000,000 Below 10,000,000	10,000,000 1,000		10,000
			1,000	,	10,000

(5) Communication output setting COMM

Setting item	Description	Content
Address [ADDRESS]	Set communication address.	ETCOMMMADDRESS Thick-frame : Default setting Image Image Image Image
Bit rate 【BIT RATE】	Set bit rate of communication.	SetICOWMPBIT RATE Thick-frame : Default setting ✓ H800 ✓ 9600 4800 bps 19200 9600 bps 38400 ✓ 1000EBACK SETISET 19200 38400 bps
Parity 【PARITY】	Set parity check method of communication.	COMMPPARITY Thick-frame: Default setting ODD Common Setting range EVEN Even number NONE Odd number EVEN Odd number EVEN Nothing
Stop bits 【STOP BIT】	Set stop bit of communication.	COMPASTOP BIT Thick-frame : Default setting I Comparison I Setting range I I I <thi< th=""> <!--</th--></thi<>

(0) contry		
Setting item	Description	Content
	Set auto off time and brightness of the display.	(Auto off time / Brightness) (Auto off time) CEGEDISPLAY RUTO-OFF LUMINANCE MODEBACK SETENTER MODEBACK SETENTER (Auto off time) Backlight auto-OFF time Thick-frame : Default setting Setting range 1 minute 10 minutes 2 minutes 15 minutes 30 minutes
Display 【DISPLAY】		【Brightness】 Backlight luminance ▲ DEFENDISPLUMI Setting range ▲ 3 5 Bright 4 1 Dark
Reset [RESET]	Reset the electric energy (Wh/varh) and setting values (SETTINGS).	Selected in the Selected in the (initialization). CFGRRESET Wh/varh SETTINGS ALL The items reset has been completed, mark (left side) is displayed. Subsequently, can also be reset the other items. Set value after a reset is the initial setting of a 3P3W (2VT2CT).
Software version [SOFTWARE]	Display version of software.	Version: 3-digits • CFG-SOFTWARE • VERSION • OO1 FTODEBRACK
Setting management number [SETTING No.]	Display setting management number specified in the setting software.	Setting management No. : 0000 to 9999©DEGREGETTINGNO.OOD1OOD1INDELBACK

(6) Configuration CFG

9. Test mo	odes
9.1 Test flow	
MENU COMENU TO DISPLA TJ TEST SETTIN MODE DSP OFF SE	OK? SET → 2.PO SET → Test IGS <= KODE <= WIRING CK menu
9.2 Test menu	
Test item	Test content
Analog output 【AO】	 Select channel (CH1 to 10) to the test. Analog output value (0, 25, 50, 75, 100 %), selected in the SET. (CH select) (Output select) (Setting 4 to 20 mA 0 to 5 V -5 to 5 V 0 % 4 mA 0 V -5 V 25 % 8 mA 1.25 V -2.5 V 0 % 12 mA 2.5 V 0 V 75 % 16 mA 3.75 V 2.5 V 100 % 20 mA 5 V 5 V
Pulse output 【PO】	 Select channel (CH11,12) to the test. Press the SET, pulse is output at one-second intervals. Once again press the SET, pulse output will stop. Pulse output number is displayed in the lower part. (0 → 1 → 2 →····→ 999 → 1000 → 1 →···) FOR CH11
Communication output 【COMM】	 Communication output value (0, 25, 50, 75, 100 %), selected in the ▲ ▼. Output in SET. Setting value — output table (110 V, 5 A) Setting value — output table (110 V, 5 A) Measurands Setting value Input Current I 0 to 100 % 0 to 5 A Current (power flow) Ipf 0 to 50 to 100 % -5 to 0 to 5 A Voltage U 0 to 100 % 0 to 150 V Active power / Reactive power P/Q 0 to 50 to 100 % -1 to 0 to 1 kW/kvar Apparent power S 0 to 100 % 0 to 1 kVA Power factor PF 0 to 50 to 100 % 45 to 65 Hz Fundamental voltage FU 0 to 100 % 0 to 150 V
Wiring check 【WIRING CK】	$ \begin{array}{c} \textbf{.} \text{ The phase angle between the voltage and current will be displayed. (U12 or U1N reference) \\ \textbf{[3P4W]} \\ \hline \textbf{[3P4W]} \\ \hline \textbf{[3P4W]} \\ \hline \textbf{[MIRING CK)} \\ \hline \textbf{[Mosurands]} \\ \hline \textbf{[MIRING CK)} \\ \hline \textbf{[Mosurands]} $

10 Specifications

10.1 Rating

	T (
	Item	Specifications	
		3-phase 3-wire [3P3W] (2VT2CT, 2VT3CT)	
Input circuit		3-phase 4-wire [3P4W] (2VT3CT, 3VT3CT)	
		1-phase 2-wire [1P2W]	
		1-phase 3-wire [1P3W] Common use (Settable)	
	3P3W	110 V AC, 50/60 Hz 220 V AC, 50/60 Hz	
	1P2W	440 V AC, 50/60 Hz Common use (Settable) (5)	
Voltage		100-200 V AC, 50/60 Hz	
input	1P3W	200-400 V AC, 50/60 Hz Common use (Settable) (⁶)	
mput	Input	$110/\sqrt{3}$ V AC, 50/60 Hz	
	3P4W	220/√3 V AC, 50/60 Hz	
		$440/\sqrt{3}$ V AC, 50/60 Hz Common use (Settable) (⁷)	
<u> </u>		5 A AC, 50/60 Hz, 0.1 VA or less	
Current in	put	1 A AC, 50/60 Hz, 0.1 VA or less Common use (Settable)	
		1) 80 to 264 V AC (Rated voltage. 100/110 V AC) 50/60 Hz, 15 VA	
	Auviliary	(Rated voltage. 200/220 V AC) 50/60 Hz, 18 VA	
	Auxiliary supply range	80 to 264 V DC (Rated voltage. 100/110 V DC) 9 W	
	and power	(Rated voltage. 200/220 V DC) 10 W	Designate
	consumption	For AC and DC use	
Auxiliary	consumption	2) 20 to 57 V DC (Rated voltage. 24 V DC) 11 W	
supply		(Rated voltage. 48 V DC) 12 W	
o app 1 y	Supply	110 V AC: 5.5 A or less	
		220 V AC: 10.9 A or less	
	Rush current	110 V DC: 3.9 A or less	
	(time constant)	220 V DC: 7.7 A or less (Approx. 5 ms)	
		24 V DC : 6.3 A or less	
		48 V DC :12.6 A or less (Approx. 8 ms)	

Note(⁵) Possible up to a maximum rating 480 V.

Power consumption: 0.25 VA or less (110 V), 0.5 VA or less (220 V), 1 VA or less (440 V)

Note(⁶) Power consumption : 0.25 VA or less (100-200 V), 0.5 VA or less (200-400 V)

note(7) Possible up to a maximum rating $480/\sqrt{3}$ V.

Power consumption : 0.25 VA or less (110/ $\sqrt{3}$ V), 0.5 VA or less (220/ $\sqrt{3}$ V), 1 VA or less (440/ $\sqrt{3}$ V)

10.2 Measurement item, Class index							
Measurement element	Measurement possible item (1, 2, 3, N:Phase, avg:Average of each phase, Σ:Total)					Class index	
	3P3W	3P4W	1P2W	1P3W	5 A	1 A	
Current	I1, I2, I3, Iavg	I1, I2, I3, IN, Iavg	Ι	I1, I3, IN	0.2	0.5	
Current (power flow)	Ipf1, Ipf2, Ipf3	Ipf1, Ipf2, Ipf3	Ipf	Ipf1, Ipf3	0.2	0.5	
Voltage	U12, U23, U31, ULLavg	U12, U23, U31, ULLavg, U1N, U2N, U3N, ULNavg	U	U1N, U3N, U13	0.2	0.2	
Active power	ΣΡ	ΣP, P1, P2, P3	Р	ΣΡ	0.3	0.5	
Reactive power (⁸)	ΣQ	ΣQ, Q1, Q2, Q3	Q	ΣQ	0.3	0.5	
Reactive power (power flow) (⁸)	ΣQpf	Σ Qpf, Qpf1, Qpf2, Qpf3	Qpf	ΣQpf	0.3	0.5	
Apparent power (9)	ΣS	ΣS, S1, S2, S3	S	ΣS	0.3	0.5	
Power factor	ΣPF	ΣPF, PF1, PF2, PF3	PF	ΣPF	1	1.5	
Power factor (power flow)	ΣPF_{Pf}	ΣPFpf, PFpf1, PFpf2, PFpf3	PFpf	ΣPF pf	1	1.5	
Frequency	f	f	f	f	0.2	0.2	
Fundamental voltage	FU12, FU23, FU31, FULLavg	FU1N, FU2N, FU3N, FULNavg	FU	FU1N, FU3N	0.3	0.3	
Active energy	Incoming, Outgoing	Incoming, Outgoing 1 2			2		
Reactive energy	Incoming LAG, Incoming	LEAD, Outgoing LAG, Outgo	ing LEAD		2	2	

Note(⁸) The calculation method can be selected. Q=UIsin ϕ or Q= $\sqrt{(S^2-P^2)}$ Note(⁹) Calculation method. 3P4W: $\Sigma S = U_{1N} \times I_1 + U_{2N} \times I_2 + U_{3N} \times I_3$, 3P3W: $\Sigma S = \sqrt{3}/2 \times (U_{12} \times I_1 + U_{23} \times I_3)$, $1P3W: \Sigma S = U_{1N} \times I_1 + U_{3N} \times I_3$

10.3 Detailed specification				
Item	Specification, Performance			
Conformity standards	Transducer, IEC 60688:2012, JIS C 1111:2019 Static meters for active energy, IEC 62053-21:2003, JIS C1271-1:2011 Static meters for reactive energy, IEC 62053-23:2003, JIS C1273-1:2011 Communication, TIA-485-A (2003)			
CE marking	EMC Directive (2014/30/EU) EN 61000-6-2 EN 61000-6-4, EN 55011 classA, Group1 Low Voltage Directive (2014/35/EU) EN61010-1			
Safety	IEC 61010−1:2010 Measurement Category III, Maximum use voltage:300 V (line to neutral), Pollution degree 2			
Operating method	<pre>Current, Voltage : RMS value computing type. Active power, Active energy : Time-division multiplication method. Reactive power, Reactive energy : Time division multiplication method (Q=UIsin¢) or the method for calculating from the power and apparent power (Q=√(S²-P²). (Selected in the setting) Apparent power : Calculates from voltage and current. Power factor : Calculates from power and reactive power. Frequency : Zero cross cycle computing type. Fundamental voltage : Fourier transform</pre>			
Operation period	5ms (Frequency measurement : Input 1 cycle)			
Influence of temperature	Usage group I 10 to 35 ℃:Within class index. 0 to 45 ℃:Within two times of a class index. -10 to 55 ℃:Within three times of a class index.			

	Item	Specification, Performance			
	Output	From elements of the	5 and output 6 to 10, insulat measurement items of Section for active energy and reacti n be selected.	10.2, it can be	
	Output rating	2) 0 to 10 V DC (3) 1 to 5 V DC (4) -5 to 5 V DC (5) -10 to 10V DC (A) 0 to 1 mA DC (B) 4 to 20 mA DC (C) -1 to 1 mA DC (Z) 0ther (Special sp	600 Ω to ∞) Switchable to 600 Ω to ∞) 2 k Ω to ∞) 10 k Ω to ∞) 0 to 550 Ω) 0 to 10 k Ω) ecification)	2 to 10 V 0 to 5 V	Designate
Analog output	Response time	Response time to be Measurements Current, Voltage Fundamental voltage Active power Reactive power Apparent power Power factor Current (power flow) Reactive power (power flow) Power factor	restored on ±1% of a final c Output CH1 to CH4, CH (High speed respondent Input 1 cycle + 10ms or less (Moving average, none) Input 1 cycle + 15ms or less (Moving average, 2 times) Input 1 cycle + 20ms or less (Moving average, 3 times) Input 1 cycle + 10ms or less (Moving average, none) Input 1 cycle + 15ms or less (Moving average, 2 times) Input 1 cycle + 20ms or less (Moving average, 2 times) Input 1 cycle + 20ms or less	H6 to CH9 onse)	Output CH5, CH10
		(power flow) Frequency	(Moving average, 3 times) Input 2 cycle + 15ms or less (Moving average, none) (fix	power	_
	Output ripple	Output ripple is below the double (peak to peak value) of a class index to an output span.			
	Current (power flow) output pattern	It is configurable to set output pattern of the reactive power (power flow) and power factor (power flow). Output pattern: 4 quadrant, 2 quadrant, Incoming only measurement (2 quadrant), Outgoing only measurement (2 quadrant)			
	Output adjuster	Bias and a span can be adjusted with each output. (For matching with a connection device.) Adjustable range : BIAS and SPAN, ±10 % (% for output span)			
	Output limiter	The minimum value and maximum value of an output can be restricted. (Setta			(Settable)

	Item	Specification, Performance						
	Output	2ch						
	Output measurands	Active energy (Incoming / Outgoing), Reactive energy (Incoming LAG / Outgoing LAG / Incoming LEAD / Outgoing LEAD)						
	Output form	Optical MOS-FET relay, Normally-open contact						
	Contact capacity	125 V AC,DC, 70 mA (Resistance load, Inductive load)						
	Pulse width	250 ± 10 ms (When the output pulse period of rated power constitutes speed more than 2 pulse / second by setting of VT primary, CT primary and output pulse rate, an output pulse width is 100 to 130 ms.)						
Pulse output		Output pulse rate can be selected in the following ranges. · 3P3W, 3P4W: Full load power (kW, kvar) = √3 × Rated voltage (V) × Rated current (A) × 10 ⁻³ · 1P3W: Full load power (kW, kvar) = 2 × Rated voltage (V) × Rated current (A) × 10 ⁻³ · 1P2W: Full load power (kW, kvar) = Rated voltage (V) × Rated current (A) × 10 ⁻³ · 1P2W is full load power (kW, kvar) · 0utput pulse rate, kWh(kvarh)/pulse						
		Below 1 0.1 0.01 0.001 0.0001						
	Output pulse	Over 1 Below 10 1 0.1 0.01 0.001						
	rate	Over 10 Below 10 1 0.1 0.01 0.01 Over 10 Below 100 10 1 0.1 0.01						
		Over 100 Below 100 100 1 0.1 Over 100 Below 1,000 100 10 1 0.1						
		Over 10,000 Below 100,000 10,000 1,000 100 100 100						
		Over 100,000 Below 1,000,000 100,000 10,000 1,000 100 000 100 000 100 000 100 100 100						
		Over 1,000,000 Below 10,000,000 1,000,000 100,000 10,000 1,000						
		Over 10,000,000 Below 100,000,000 10,000,000 1,000,000 100,000 10,000						
	Output	1ch						
	Communication system	RS-485 Half-duplex two-wire system, asynchronous communication method						
	Protocol	MODBUS RTU						
	Bit rate	4800 bps / 9600 bps / 19200 bps / 38400 bps						
	Transmission code							
	Start bit							
		1 bit						
Communication	Data bit	8 bits						
output	Parity	None / Even number / Odd number						
·	Stop bit	1 bit / 2 bits						
	Transmission character	Binary						
	Cable length	1000 m (Max.)						
	Address	1 to 247 (Max. connectable: 31 units)						
	Error detection	CRC-16 (X ¹⁶ +X ¹⁵ +X ² +1)						
	Termination							
	resistor	100 Ω , 1/2 W, Install to the terminal. (Accessory)						
	Point	1ch						
	Function							
USB	Version	Read-out and update the setting values are possible by connecting to PC.						
USD		USB 2.0						
	Transfer rate	12Mbps						
	Connector	USB Type-C						
	Analog output	Without any input, and outputs an analog output (1 to 10 individual). O, 25, 50, 75% output.						
Test	Communication output	Without any input, and outputs an measured value of communication output. 0, 25, 50, 75% output.						
function	Pulse output	Without any input, and outputs an pulse output (1 to 2 individual).						
	Input wiring	1s/1pulse						
	Input wiring	The wiring state of the AC input (each input of the phase) is displayed on the screen.						
	Diantes al	OLED display unit, 1 inch , Resolution: 128×96 dots						
Display	Display element	Luminescent color: White						
		Display automatic turn off (automatic turn off time after no operation can be set)						
	Function	The measured value (% display) of each measurement item can be checked on the screen						
		display.						

Item	Specification, Performance		
Power interruption backup	Active energy, reactive energy, and each setting value are retained in non-volatile		
	memory.		
	Between electric circuit and ground. Between AC input and output (analog output, pulse output,		
	communication output) and auxiliary supply.	50 MΩ or more at 500 V DC	
	Between analog output and pulse output.		
	Between pulse output and communication output.		
Insulation resistance	Between pulse output 1 and pulse output 2.		
	Between analog output1 to 5 and analog output6 to 10 and		
	communication output.		
	Non-insulation (Minus common): Between analog output 1 to 5,	between analog output	
	6 to 10.		
	Between electric circuit and ground.	2210 V AC (50/60 Hz)	
	Between AC input and output (analog output, pulse output,	5 seconds	
	communication output) and auxiliary supply.		
	Between analog output and pulse output.	1390 V AC (50/60 Hz)	
Voltage test	Between pulse output and communication output. Between pulse output 1 and pulse output 2.	5 seconds	
	Between analog output 1 to 5, analog output 6 to 10 and	500 V AC (50/60 Hz)	
	communication output.	5 seconds	
	Non-insulation (Minus common) : Between analog output 1 to 5,		
	6 to 10.		
	Between auxiliary power supply, AC input and ground.		
	(Analog output, pulse output, and communication output		
	are grounded)		
	Between auxiliary supply and AC input, analog output,		
	pulse output, communication output, ground.	6kV 1.2/50µs	
	Between AC input and auxiliary supply, analog output,		
Impulse voltage test	pulse output, communication output, ground.		
	Between three-phase voltage input terminals.		
	Between auxiliary supply terminals. Between pulse output and auxiliary supply, AC input,		
	analog output, communication output, ground.		
	Between external input and auxiliary supply, AC input, 2.5kV 1.2/50 µs		
	analog output, pulse output, communication output, ground.		
	Peak voltage: 2.5 kV, frequency: 1 MHz \pm 10 %, Add 3 times for 30 seconds.		
Damped oscillatory wave	Error: Within ± 10 %. And, malfunction and communication stop must not occur.		
immunity test	• AC voltage input circuit (Normal / Common)		
IEC61000-4-12	• AC current input circuit (Common)		
	· Auxiliary supply circuit (Normal / Common) Add noise (1 μ s, 100 ns width) repeatedly for 5 minutes. Error:Within ±10 %.		
	And, malfunction and communication stop must not occur.	$1101 \cdot WILIIII \pm 10 \%$.	
	Auxiliary supply circuit (Normal / Common) 1.5 kV or more		
Square impulse immunity test	• AC voltage input circuit (Normal / Common) 1.5 kV or more		
JEA B-402	• AC current input circuit (Common) 1.5 kV or more		
	Pulse output (Common) 1.0 kV or more		
	Analog output (Induction) 1.0 kV or mor		
	Communication output circuit (Induction) 1.0 kV or more		
	Radio wave band:5W, 1m on 150 MHz, 400 MHz band. Cellular phone, wireless LAN:2.4 GHz, 5 GHz band.		
Radio wave immunity test	Continued irradiation with radio wave on 0.5 m. Error:Within ±10 %.		
	And, communication should communicate normally after a noise applying stop.		
	Usually, it tests by the busy condition.		
Electrostatic discharge	When powered up.		
immunity test	Air discharge: 15 kV, Contact discharge: 8 kV, Error: Within ± 10 %.		
IEC 61000-4-2	And, malfunction and communication stop must not occur.		
	Capacitor charge system		
Vibration	IEC 60068-2-6: 2007	Curean evel + 10 + 1	
	Frequency range: 10 to 55 Hz, Single amplitude: 0.15 mm,	sweep cycle . IU times	
Impact	IEC $60068-2-27$: 2008 Peak acceleration: 500 m/s ² (Screw installation), 300 m/s ² (DIN rail installation)	
	1 + car acceleration + 500 m/s (Screw Histallation), SUU m/s (vin fart Histatlativil)	

Item		Specification, Performance	
	Input	2 times 10 seconds and 1.2 times continuation of rated voltage. 40 times 1 second, 20 times 4 seconds, 10 times 16 seconds, 1.2 times continuation of rated current.	
Overload capacity	Auxiliary supply	<pre>1.5 times 10 seconds and 1.2 times continuation of rated voltage. (100/110 V AC, 200/220 V AC, 24 V DC, 48 V DC) 1.5 times 10 seconds and 1.3 times continuation of rated voltage. (110 V DC, 220 V DC)</pre>	
	Output	Voltage output: Short circuit for 1 second by 10 times at 10 seconds interval short circuit for 5 seconds, 70 % continuation of rated-output load. Current output: Open continuation, 130 % continuation of rated-output load.	
	Case outline	109 \times 92 (With mounting legs, 120) \times 115 mm (W \times H \times D)	
	Mass	Approx. 700g	
Construction	Material	Case:ABS (V-0) Terminal board:ABS (V-0) Terminal cover:PET-GF (HB)	
	Terminal screw	Upper side terminal (Auxiliary supply, AC input, Ground terminal): M4 screw Lower side terminal (Analog output, Pulse output, Communication output): M3 scr	
	Protection rating	IP30	
Operating temperature and humidity limits		-10 to 55℃, 5 to 90% RH (Non condensing)	
Storage temperature limits		-25 to 70℃	

10.4 Measuring range

Measurands	Rated vo Rated cu		Measuring range	Low input cut	Display
Current	_	5 A	0 to 5 A	Less than 0.2 % of the rated (¹⁰)	0 0 to 100 0[V]
Current	_	1 A	0 to 1 A	Less than 0.5 % of the rated (¹⁰)	0.0 to 100.0[%]
Current	_	5 A	Outgoing 5 A to Incoming 5 A (¹¹)	Less than 0.2 % of the rated (¹⁰)	-100.0 to 100.0[%]
(Power flow)	_	1 A	Outgoing 1 A to Incoming 1 A (¹¹)	Less than 0.5 % of the rated (¹⁰)	
	110 V	-	0 to 150 V (1P3W:0 to 300 V)	Less than 1 % of	
Line voltage	220 V	-	0 to 300 V (1P3W:0 to 600 V)	full scale	0.0 to 100.0[%]
	440 V	-	0 to 600 V		
	110 V	-	3P4W∶0 to 150/√3 V 1P3W∶0 to 150 V	less than 1 % of	
Phase voltage	220 V	_	3P4W∶0 to 300/√3 V 1P3W∶0 to 300 V	Less than 1 % of full scale	3P4W:0.0 to 57.7[%] 1P3W:0.0 to 50.0[%]
	440 V	Ι	3P4W∶0 to 600/√3 V		
	110 V		-1 to 1 kW (¹²)	less than 0.2 % of	
	220 V	5 A	-2 to 2 kW (¹²)	Less than 0.3 % of	ΣΡ:
Active newer	440 V		-4 to 4 kW (¹²)	the rated	-100.0 to 100.0[%]
Active power	110 V		-200 to 200 W (¹²)	lace than 0 E V of	P ₁ , P ₂ , P ₃ :
	220 V	1 A	-400 ± 6 400 W (12)	Less than 0.5 % of	-33.3 to 33.3[%]
	440 V		-800 to 800 W (12)	the rated	

Note(10) Low input cut value of the N-phase current is twice.

Note(11) The polarity of the current (power flow) is the same polarity as the power ΣP .

Less than 20% of the voltage full scale, then output as the incoming side.

Note(12) 1P2W: Active power measurement range is 1/2 of the above.

3P4W: Each phase of the active power measurement range is 1/3 of the above. O to +P or O to -P or -P to +P, can be set.

Measurands	Rated volta Rated curre		Measuring range	Low input cut	Display
Reactive power, Reactive power	110 V	δA	LEAD 1 to LAG 1 kvar (¹³) LEAD 2 to LAG 2 kvar (¹³) LEAD 4 to LAG 4 kvar (¹³)	Less than 0.3 % of the rated	ΣQ: -100.0 to 100.0[%]
(power flow)	440 V	IA	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	Less than 0.5 % of the rated	Q1, Q2, Q3: -33.3 to 33.3[%]
Apparent power	440 V	5 A	0 to 1 kVA (¹⁴) 0 to 2 kVA (¹⁴) 0 to 4 kVA (¹⁴)	Less than 0.3 % of the rated	∑S: 0.0 to 100.0[%]
	110 V 220 V 1 440 V	A	0 to 200 VA (¹⁴) 0 to 400 VA (¹⁴) 0 to 800 VA (¹⁴)	Less than 0.5 % of the rated	S1, S2, S3: 0.0 to 33.3[%]
Power factor, Power factor (power flow)	770 V	5 A I A	LEAD 0 to 1 to LAG 0 LEAD 0.5 to 1 to LAG 0.5 LAG 0 to 1 to LEAD 0 LAG 0.5 to 1 to LEAD 0.5	Less than 20 % of the voltage full scale, or less than 2 % of the rated current. Incoming power factor 1.	LEAD to LAG: -0.0 to 100.0 to 0.0[%] LAG to LEAD: 0.0 to 100.0 to -0.0[%]
Frequency (¹⁵)	110 V 220 V 440 V	_	45 to 55 Hz 55 to 65 Hz 45 to 65 Hz	Output lower nominal value in less than 20 % of the full scale voltage (Example:4 mA)	45.0 to 65.0[Hz] Low input cut:0.0[Hz]
Fundamental voltage	110V 220V 440V	_	Measuring range is same as "voltage". 3P4W, 1P3W: Phase voltage 3P3W, 1P2W: Line voltage	Less than 1 % of voltage full scale	Measuring range is same as "voltage". 3P4W, 1P3W:Phase voltage 3P3W, 1P2W:Line voltage
Active energy	220 V	5 A I A	O to 999999999 kWh(MWh) By the setting and the full load power, position and unit of the decimal point (k/M) is changed	_	0 to 999999999 kWh(MWh)
Reactive energy	2201 V	ō A I A	O to 9999999999 kvarh(Mvarh) By the setting and the full load power, position and unit of the decimal point (k/M) is changed	_	0 to 999999999 kvarh(Mvarh)

Note(¹³) 1P2W: reactive power measurement range is 1/2 of the above.

3P4W:Each phase of the reactive power measurement range is 1/3 of the above.

0 to LAG Q or 0 to LEAD Q or LEAD Q to LAG Q, can be set.

Note(14) 1P2W: Apparent power measurement range is 1/2 of the above.

3P4W:Each phase of the apparent power measurement range is 1/3 of the above.

Note(¹⁵) Line voltage U₁₂ (3P3W, 1P2W) or phase voltage U_{1N} (3P4W, 1P3W) to measure the frequency.

Input frequencies can be measured from 10 to 180 Hz, but accuracy is guaranteed from 45 to 66 Hz. Also, for measurements of 70 Hz or higher, an input of 40% or more of the voltage full scale is required.









11 Multi-transducer setting software (QT2-CS-01)

11.1 Outline

Multi-transducer setting software (QT2-CS-O1) is a QT2-500/HSQT2-500 dedicated setup tool. Software can be downloaded at the WEB site. (URL; https://www.daiichi-ele.co.jp/) The following data management is possible by connecting HSQT2-500 and PC with a USB cable.

- Edit and save setting data.
- Write setting data into HSQT2-500.
- Read setting data from HSQT2-500.
- Output the setting data in CSV file.

11.2 Hardware requirements

Item	Specification
Personal Computer	PC-AT based computer
	Windows® 8.1 (32 bits / 64 bits)
Operating System	Windows® 10 (32 bits / 64 bits)
	Windows® 11 (64 bits)
СРИ	32-bits processor:1 GHz or more
CPU	64-bits processor:1.6 GHz or more
Memory	32-bits processor:1 GB or more,
мешоту	64-bits processor:2 GB or more
	Free space 100 MB or more
HDD	[If the Microsoft .NET Framework 4 Client Profile (32-bit) or Microsoft .NET Framework 4.5 (64-bit) is not installed. Free space of 300 MB or more]
Display	Resolution: 1024×768 or higher, High Color (65536 colors) or higher
Interface	USB2. 0
Communication port	USB (A) port ×1
Other	Mouse, Keyboard

11.3 System configuration





Installation, connection, such as the operation method, please refer to the included manual to QT2-CS-01.

12 Troubleshooting

Trouble	Probable cause	Handling
Power LED is not lights	In the 13th and 14th terminals, auxiliary	Please by applying an auxiliary
	power supply is not applied.	power supply.
Display disappears	By auto off function, display is off	Please press the switch
Does not switch to the	By the lock function of the test /	Please to unlock.
setting mode or test mode	configuration.	Pressing the MODE and SET at the
		same time for three seconds.
		Unlock or setting.
Error in analog output	Setting of VT rating and CT rating is wrong	Please check the VT/CT settings
	Output element setting is wrong	Please check the output element
		setting of each output CH
	Range setting of each measurement items is	Please check the range settings for
	wrong	each measurement items
	Setting of analog output is wrong	Please check the settings of the
	(0 to 5 V, 1 to 5 V, 0 to 10 V, 2 to 10 V)	analog output
	Wiring is wrong	Please check with the test mode
		wiring check function
Error in communication	Setting of VT rating and CT rating is wrong	Please check the VT/CT settings
output	Wiring is wrong	Please check with the test mode
		wiring check function
Error in active energy and	Setting of VT rating and CT rating is wrong	Please check the VT/CT settings
reactive energy.	Pulse rate setting is wrong	Please check the setting of the
(Display, Communication,		output pulse rate
Pulse output)	Wiring is wrong	Please check with the test mode
		wiring check function

⊖ DAIICHI ELECTRONICS CO., LTD.

Tokyo Office : 11-13, Hitotsuya 1-chome, Adachi-ku, Tokyo, 121-8639, JAPAN. TEL : +81-3-3885-2411 , Fax : +81-3-3858-3966

Kyoto Office : 1-19, Ichinobe-Nishikawahara, Jyoyou-shi, Kyoto, 610-0114, JAPAN. TEL : +81-774-55-1391 , Fax : +81-774-54-1353

Revision A, DATE: December 3, 2024